

MBK-45

MONOBLOCK VALVE FLOW LIQUIDS

GENERAL FEATURES

Damage to the sealing surfaces can occur for the following reasons:

- During closing time, due to solid particles are trapped between the ball and ring cause scrating on the surfrace of ball and/or seat.
- Corrosion in seat rings
- Deformation of the seat ring due to overheating.

When opening and closing the valve, apply force in the direction of the arrow indicated on the arm.Do not continue to apply force when the arm is compliant with the stopper pin.If the valve does not open and close with a suitable shut-off torque, do not force the valve using a jimmy or similar device to increase the shut-off torque. This can increase irreparable damage to the valve parts.

Attention:

Avoid physical intervention from the outside to the valve body without precautions for accidental closure.

Avoid sudden rapid on-offs to prevent the formation of water hammer in ball valves

Important

Open and close the valve once a week with the aim of preventing the formation of lime and sediment layer which may form on the surface of the sphere when the valve should wait for a long time in closed position in the installation.

Advantages

- Lightweight Monoblock Design
- Short Flange Distance
- Space-Saving
- Easy Installation
- Universal Application

Installation:

Can be install in every direction.

Application Areas:

- On cold-hot water pipelines
- Natural gas, LPG-LNG, Fuel-Oil Compressed Air
- Ship manufacturing sector
- Storage facilities


TECHNICAL SPECIFICATION		
Connection	Flanged	
Gasket	Water: EPDM	
Casket	Gas: NBR	
Temp. Range	-40/+110°C	
Pressure Class	PN16	

DIMENSIONS (mm)			
Diameter(DN)	20	25	


Factor	RISK	SOLUTION
Maximum and minimum temp.	Exceeding the temperature limits	The end user should avoid exceeding the limit specified in the use and maintenance manual.
Corrosion	Leak as a result of corrosion on the sealing surfaces. Decrease in working life.	Avoid process fluids containing corrosive particle and wastes which cam damage the valve sealing.
	Breaking	This should be avoided or prevented by the end
Shock	Damage to pressurized parts due to water hammer.	user.Steamtraps must be installed where necessary to prevent the water hammer.
Thermal Shock	Different thermal expansion	This should be avoided or prevented by the end user.


MBK-45 MONOBLOCK VALVE FLOW LIQUIDS


DN20 TECHNICAL SPECIFICATIONS



DN25 TECHNICAL SPECIFICATIONS









HEAD OFFICE - FACTORY

Atatürk Sanayi Bölgesi Hadımköy Mahallesi Mustafa İnan Caddesi No: 44 Arnavutköy - İSTANBUL Tel: +90 212 771 01 45 (pbx) | Fax: +90 212 771 47 27 info@ayvaz.com | www.ayvaz.com

C	OH	u				
C	as	erto	1 /	Itc	ıly	/
_			_		_	

Tel: +39 0823 187 3988 rmolaro@ayvaz.com

Ayvaz Germany Viernheim/Germany Tel: +49 62046014399 germany@ayvaz.com

Ayvaz Ukraine Kiev/Ukraine Tel: +380 44 390 57 57 info@ayvaz.com.ua

Tricorr Warsaw/Poland

Tel: +48 530 030 810 +48 533 603 335 tricorr@tricorr.eu

Ayvaz Azerbaijan Baku/Azerbaijan

Tel: +99 (455) 579-84-32 ahayatov@ayvaz.com

Ayvaz Egypt Cairo/Egypt

Tel: +20 122 819 78 29 andrew.eid@ayvaz.com

Ayv	az G	ulf
Dub	ai/U	.A.E
Tal.	. 0.71	ECSEEC

+971 501306871 : mideast@ayvaz.com:

Ayvaz China Ningbo/China

Tel: +86 152 5830 7361 msahin@ayvaz.com

Ayvaz Kazakhstan LLP : Ayvaz N Almaty/Kazakhstan Tel: +7 (727) 327 97 57 info_kz@ayvaz.com

.....

Isperih/Bulgaria office@ayvaz-n.eu

: Ayvaz Serbia Belgrade/Serbia

Tel: +359 8431 27 32 : Tel: +381 61 658 70 52 : : yakbiyik@ayvaz.com :

: Ayvaz Vietnam HCMC/Vietnam ggursoy@ayvaz.com

Tel: +84 89 8508345

: Ayvaz Americas Rhode Island/USA Tel: +1 401 737 8380 : americas@ayvaz.com